

LISTER LEGATO - Changing the bottom blade and the top blade

- Undo both screws on the blade set; remove the bottom blade and the top blade (Fig. 7).
- Before assembly, the bearing surfaces of the bottom blade and the top blade should be oiled.
- When assembling, the bottom blade and the top blade should be aligned as follows:
 - **Set the cutting length adjustment lever to the shortest cutting length** (min) (Fig. 4a).
- Place the top blade with the guide groove on the wedge-shaped plastic guide (Fig. 8a) so that the drive pin (Fig. 8b) engages in the engaging device cutout on the top blade.
- Place the bottom blade with the guide groove onto the side of the slide spring (Fig. 9a) and press it against the slide spring (Fig. 9b). Press the top blade down until it snaps into the groove (Fig. 9c).
- The top blade must be parallel with the bottom blade with a gap of 0.5 – 1.0mm (1/6th") before tightening the screws (Fig. 10).
This gap must also be maintained after removing the cutting comb for cleaning and subsequently replacing it. Failure to maintain this gap could result in injury.
- Tighten both screws (Fig. 7).

